


"DH" SERIES HYDRAULIC DOCK LEVELERS

























installation and operating instructions

GOOD SAFETY PRACTICES

DOCK LEVELING DEVICES

LEARN THE SAFE WAY TO OPERATE THIS EQUIPMENT. READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTIONS. IF YOU HAVE ANY QUESTIONS, ASK YOUR SUPERVISOR.

	STAY CLEAR OF DOCK LEVELING DEVICE WHEN FREIGHT CARRIER IS ENTERING OR LEAVING AREA.	
	CHOCK / RESTRAIN ALL FREIGHT CARRIERS.	
	DO NOT USE A BROKEN OR DAMAGED DOCK LEVELING DEVICE.	
	DO NOT MOVE OR USE THE DOCK LEVELING DEVICE IF ANYONE IS UNDER OR IN FRONT.	
	KEEP HANDS AND FEET CLEAR OF PINCH POINTS.	
	LIP MUST REST SECURELY ON FREIGHT CARRIER BED.	
	DO NOT USE DOCK LEVELING DEVICE IF FREIGHT CARRIER IS TOO HIGH OR TOO LOW.	
	DO NOT OVERLOAD THE DOCK LEVELING DEVICE.	
	KEEP A SAFE DISTANCE FROM BOTH SIDE EDGES.	
	DO NOT OPERATE ANY EQUIPMENT WHILE UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.	
	DO NOT LEAVE EQUIPMENT OR MATERIAL UNATTENDED ON DOCK LEVELING DEVICE.	

INSTALLATION INSTRUCTIONS FOR HYDRAULIC DOCK LEVELERS

WARNING

Always use safe work habits.

Always secure leveler before attempting any procedure where personnel or equipment will enter the area around the leveler. Failure to observe these and other safety rules may result in personal injury and/or property damage.

1. Check pit for proper construction. For a hydraulic system there must be a junction box in the pit with conduit running to a near wall where a control box is to be mounted. Refer to Figure 1 for typical set-up. Check to make sure walls are square and plumb. Clean out all debris.




Figure 1

2. There are ten (10) load bearing points related to the main frame. Five (5) are at the rear of frame under the five (5) support posts, four (4) are at the front of frame under the cross-traffic supports, and one (1) is under the cylinder mounting angle at the center of frame. (See Figure 2)

3. Refer to Figure 3 and use the following method to measure pit depth at specific load-bearing points:
 - a. Place a straight-edge across the width of the pit 6 1/2" from the back wall.
 - b. Measure down from the bottom of the straight-edge to the bottom of the pit at two (2) rear corner load-bearing points.
 - c. Move the straight-edge 2" from the front of pit and take a measurement for the two (2) front load bearing points.




Figure 2




Figure 3

4. If any point measurement is larger than 18 5/8" shim up the difference at that point.
5. If any point measurement is less than 18 5/8" chisel out the bottom of the pit at that point.
6. Position the dock leveler in the pit (See Figure 4) making sure the electrical wire coming out of junction box at the rear of pit does not become crimped between the unit frame and pit. (See Figure 5)




Figure 4




Figure 5

7. Once the leveler has been set in pit make sure all four (4) corners are flush with dock surface.
8. Once a flush fit has been obtained all around the board, tack weld the two (2) rear welding angles together. (See Figure 5)

WARNING

Leveler should not be operated until rear angle of unit is welded to pit angle.

9. Utilizing the fork lift, raise lip and deck until frame is exposed. (See Figure 6)




Figure 6

WARNING

When working under the open board, use the maintenance strut.

10. It is recommended that a licensed electrician perform the following:
 - a. Install electrical control box on conduit to pit junction box.
 - b. Make electrical connections from unit junction box to pit junction box to electrical control box.
(See Electrical Schematic)
11. If required, shim remaining load bearing points. Tack weld all shims to frame. To prevent shifting, weld the front shims to the angle.
12. Finish welding rear welding angles together. Remove safety bar and fork lift and installation is now complete.



OPERATING INSTRUCTIONS FOR HYDRAULIC DOCK LEVELERS

WARNING

Read all warnings and instructions and become familiar with operating procedures before attempting to operate leveler. Failure to follow these and other safe work habits may result in personal injury and/or property damage.

WARNING

Do not operate leveler while any equipment or personnel are standing on or in front of leveler.

Do not activate leveler until truck is situated squarely against bumpers and truck wheels are securely chocked.

Do not walk or drive any equipment on leveler until all motion has stopped and lip rests securely on bed of truck.

Always return dock leveler to safe cross traffic position after loading or unloading operations are completed

Always use safe work habits.

1A

If unloading be sure to keep leveler in stored position until extreme end load has been removed. Premature operation of dock leveler may damage end load.

After any end load has been removed, actuate the leveler by pushing and holding the raise button on the control box until the leveler has reached its full operating height and the lip is fully extended.

Release the raise button and the deck will slowly fall until the lip rests on the truck bed. Complete loading or unloading operation.

The leveler may be retracted from the truck by pushing and holding the raise button until the lip is fully retracted, after the raise button is released, the leveler will descend to its stored position.

MAINTENANCE/LUBRICATION

Dirt is the single greatest threat to hydraulic system reliability. Each dirt particle generates additional particles due to abrasive action. Care should then be taken to prevent dirt from entering the system. Failure to follow standard hydraulic service procedures may allow foreign particles to be introduced into the system causing accelerated wear, sticking of parts, loss of efficiency, and premature failure of components.

Caution: Wipe all foreign material from around fill port prior to removing fill port cap.

For proper operation, cleaning and lubrication should be performed every 90 days or sooner depending on usage.


Grease all fittings on piano hinges and oil cylinder pivots every 90 days. At this time inspect all hoses and fittings, replace any worn parts. Check fluid level using dipstick. Oil level should be within 3 inches of top of reservoir with cylinders fully extended. Use only Dexron II ATF. In colder climates use JNIVIS J-13 or equivalent.

Caution: Do not attempt to cycle or operate leveler while personnel are in the vicinity of the understructure or lip area of the leveler. This may result in personal injury and/or property damage.

WARNING

Always have maintenance strut in position when working under open board.

1. Set-up lubrication procedure on a regular basis approximately every three (3) months.
2. Zerk fittings are provided on all grease applications.





OPERATING INSTRUCTIONS FOR HYDRAULIC DOCK LEVELERS (continued)

DHB

The DHB series operates identically to the DHA series except for the addition of the automatic mode of operation. When the AUTO mode is selected the dock leveler will return automatically to a safe cross traffic position after a truck departs.

Except for extreme end load below dock operations the dock leveler can be operated in the AUTO mode at all times.

For extreme end load below dock operations the leveler must first be put in the manual position on the control box. Actuate the leveler until the lip plate extends partially (approximately 2") then release the raise button. The leveler will then descend to its lowest position and any end load may be removed.

After the truck departs you may return the control box to the AUTO mode and the leveler will return to a safe cross traffic position.

DHC

The DHC series have two additional controls which provide for greater speed and flexibility of loading dock operations. Operation is similar to the DHB series except for the additional two controls.


1. The DHC series allows the operator to "short cycle" the dock leveler by pushing and holding the raise button until the leveler has reached a point high enough for the lip plate to clear the truck bed. Then push the lip extend button. The levelers upward motion will stop and the lip plate will extend.

WARNING

The stop feature is not intended to provide a service mode and no one should ever enter the pit area without the maintenance strut securely in place.

Leveler remains stationary in stop mode only as long as system is energized. Should power be interrupted the leveler will descend.

UNDERSTRUCTURE ASSEMBLY



ITEM	DESCRIPTION	PART NO.
1	DH6525	8350
1	DH6530	8351
1	DH6625	8352
1	DH6630-35	8353
1	DH6645	8354
1	DH6650	8355
1	DH6660	8356
1	DH6.5625	8357
1	DH6.5630-35	8358
1	DH6.5645	8359
1	DH6.5650	8360
1	DH6.5660	8361
1	DH6825	8362
1	DH6830-35	8363
1	DH6845	8364
1	DH6850	8365
1	DH6860	8366



UNDERSTRUCTURE ASSY (continued)


ITEM	DESCRIPTION	PART NO.
1	DH6.5825	8367
1	DH6.5830-35	8368
1	DH6.5845	8369
1	DH6.5850	8370
1	DH6.5860	8371
1	DH6.1025-30	8372
1	DH6.51025-30	8373
1	DH7625-30	8380
1	DH7645	8381
1	DH7650	8382
1	DH7660	8383
1	DH7825-35	8384
1	DH7845	8385
1	DH7850	8386
1	DH7860	8387
1	DH71025-30	8388
1	DH7880	8389

ITEM	DESCRIPTION	PART NO.
2	DH 5 ft. Prop Bar Assy	8408
2	DH 6 ft. Prop Bar Assy	8409
2	DH 8 ft. Prop Bar Assy	8410
2	DH 10 ft. Prop Bar Assy	8411
2	DH 6 ft. 60K Prop Bar Assy	8412
2	DH 8 ft. 60K Prop Bar Assy	8413

ITEM	DESCRIPTION	PART NO.
3	Motor & Pump, 1/2 hp - 1 ph MTE # S201T - 3425	2701
3	Motor & Pump, 1 hp - 1 ph MTE # S202T - 3427	2704
3	Motor & Pump, 1 hp - 3 ph MTE # S202T - 3426	2707
3	Motor & Pump, 1 hp - 3 ph	2708
3	Motor & Pump, 1 hp - 1 ph "Barns"	2706
3	Motor & Pump, 1 hp - 3 ph "Barns"	2709

ITEM	DESCRIPTION	PART NO.
4	Junction Box A-604LP	2613

DECK ASSEMBLY





ITEM	DESCRIPTION	MODEL	ASSY NO.
1	Lip Plate Assy	DH 6 ft. - 16/25K	8287
1	Lip Plate Assy	DH 6 ft. - 18/25K	8288
1	Lip Plate Assy	DH 6 ft. - 20/25K	8289
1	Lip Plate Assy	DH 6 ft. - 16/30K	8335
1	Lip Plate Assy	DH 6 ft. - 18/30K	8336
1	Lip Plate Assy	DH 6 ft. - 20/30K	8337
1	Lip Plate Assy	DH 6 ft. - 16/35K	8338
1	Lip Plate Assy	DH 6 ft. - 18/35K	8339

DECK ASSEMBLY (continued)


ITEM	DESCRIPTION	MODEL	ASSY NO.
1	Lip Plate Assy	DH 6 ft. - 20/35K	8340
1	Lip Plate Assy	DH 6 ft. - 16/45K	8293
1	Lip Plate Assy	DH 6 ft. - 18/45K	8294
1	Lip Plate Assy	DH 6 ft. - 20/45K	8295
1	Lip Plate Assy	DH 6 ft. - 20/50K	8296
1	Lip Plate Assy	DH 6 ft. - 20/60K	8297
1	Lip Plate Assy	DH 6.5 ft. - 16/25K	8298
1	Lip Plate Assy	DH 6.5 ft. - 18/25 K	8299
1	Lip Plate Assy	DH 6.5 ft. - 20/25K	8300
1	Lip Plate Assy	DH 6.5 ft. - 16/30K	8341
1	Lip Plate Assy	DH 6.5 ft. - 18/30K	8342
1	Lip Plate Assy	DH 6.5 ft. - 20/30K	8343
1	Lip Plate Assy	DH 6.5 ft. - 16/35K	8344
1	Lip Plate Assy	DH 6.5 ft. - 18/35K	8345
1	Lip Plate Assy	DH 6.5 ft. - 20/35K	8346
1	Lip Plate Assy	DH 6.5 ft. - 16/45K	8304
1	Lip Plate Assy	DH 6.5 ft. - 18/45K	8305
1	Lip Plate Assy	DH 6.5 ft. - 20/45K	8306
1	Lip Plate Assy	DH 6.5 ft. - 20/50K	8307
1	Lip Plate Assy	DH 6.5 ft. - 20/60K	8308
1	Lip Plate Assy	DH 7 ft. - 16/25K	8319
1	Lip Plate Assy	DH 7 ft. - 18/25K	8320
1	Lip Plate Assy	DH 7 ft. - 20/25K	8321
1	Lip Plate Assy	DH 7 ft. - 16/30K	8347
1	Lip Plate Assy	DH 7 ft. - 18/30K	8348
1	Lip Plate Assy	DH 7 ft. - 20/30K	8349
1	Lip Plate Assy	DH 7 ft. - 16/35K	8423
1	Lip Plate Assy	DH 7 ft. - 18/35K	8424
1	Lip Plate Assy	DH 7 ft. - 20/35K	8425
1	Lip Plate Assy	DH 7 ft. - 16/45K	8325
1	Lip Plate Assy	DH 7 ft. - 18/45K	8326
1	Lip Plate Assy	DH 7 ft. - 20/45K	8327
1	Lip Plate Assy	DH 7 ft. - 20/50K	8328
1	Lip Plate Assy	DH 7 ft. - 20/60K	8329
2	6 ft. Lip Hinge Pin Assy Kit	All 6 ft.	6446
2	6.5 Lip Hinge Pin Assy Kit	All 6.5 ft.	6447
2	6 ft. Heavy Duty Lip Hinge pin Kit	All 6 ft.	6448
2	6.5 ft. Heavy Duty Lip Hinge pin Assy Kit	All 6.5 ft.	6449
2	7 ft. Hinge Pin Assy Kit	All 7 ft.	7160
2	7 ft. Heavy Duty Lip Hinge Pin Assy Kit	All 7 ft.	7161
3	Limit Switch	All B & C	2628
4	5 ft. Left Toe Guard Assy	5 ft.	6208
4	5 ft. Right Toe Guard Assy	5 ft.	6209
4	6 ft. Left Toe Guard Assy	6 ft.	6210
4	6 ft. Right Toe Guard Assy	6 ft.	6211
4	8 ft. Left Toe Guard Assy	8 ft.	6212
4	8 ft. Right Toe Guard ssy	8 ft.	6213
4	10 ft. Left Toe Guard Assy	10 ft.	6214
4	10 ft. Right Toe Guard Assy	10 ft.	6215



ILLUSTRATED PARTS BREAKDOWN - HYDRAULIC CYLINDER ASSEMBLIES



ITEM	DESCRIPTION	PART NO.
1	90 degree, 3/8" x 3/8"	2740
2	Velocity Fuse	2765
3	Runtee, 3/8"m x 3/8"t x 3/8"t	2741
4	Flow Control, 3/8"t x 3/8"t	2768
5	Nipple, 3/8" x 3/8"	2748
6	Herschmann Connector	2639
7	Hyd. hose assy, 3/8" hose x 8" 3/8"m (ridge) x 3/8"m (swivel)	8485
8	4-way cross, 3/8" all female	2742
9	90 degree swivel, 3/8"m x 1/4"t	2739
10	Elbow, 3/8"m x 3/8"t	2743
11	Main cylinder, 4" x 20"	2727
12	90 degree swivel, 1/4"m x 1/4"t	2738
13	Lip cylinder, 2" x 6"	2725
14	Hose assy, 3/8" x 11 1/2" 3/8"m (ridge) x 3/8" (swivel)	8486



NOTE

BRANCH MOTOR
PROTECTION PER NEC
REQUIRED

SCHEMATIC, TYPE DHA, SINGLE PHASE

NOTE


MOTOR BRANCH CIRCUIT PROTECTION MUST BE PROVIDED BEFORE THIS CONTROL PANEL.

MOTOR DATA

115 VAC , H-37 HTR
1 HP AT 16 F.L.A.
230 VAC , H-29 HTR
1 HP AT 8 F.L.A.

INCOMING SERVICE

115 OR 230 VAC
1 PH
60 HZ



NOTE

ENCLOSURE MUST BE CONNECTED TO A GOOD EARTH GROUND

INCOMING SERVICE

200, 230 OR 460 VAC
3 PH
60 HZ

MOTOR DATA


200 VAC, M-25 HTR
1 HP AT 4.1 F.L.A.
230 VAC, M-24 HTR
1 HP AT 3.6 F.L.A.
460 VAC, M-17 HTR
1 HP AT 1.8 F.L.A.

NOTE

MOTOR BRANCH CIRCUIT
PROTECTION MUST BE
PROVIDED BEFORE THIS
CONTROL PANEL.

TRANSFORMER CONNECTION

200 V
230 V
460 V



NOTE

ENCLOSURE MUST BE
CONNECTED TO A GOOD
EARTH GROUND.

L1 L2 L3 3 5 6 7 DI D2
● ● ● ● ● ● ● ● ●



INCOMING SERVICE

115 OR 230 VAC
 1 PH
 60 HZ

MOTOR DATA


115 VAC , H-29 HTR
 1/2 HP AT 9.8 F.L.A.
 115 VAC , H-37 HTR
 1 HP AT 1.6 F.L.A.
 230 VAC , H-29 HTR
 1 HP AT 8 F.L.A.

NOTE

MOTOR BRANCH CIRCUIT PROTECTION MUST BE PROVIDED BEFORE THIS CONTROL PANEL.

TRANSFORMER CONNECTION

115 V
 230 V



* REMOVE JUMPER FOR OVERHEAD DOOR INTERLOCK

NOTE



ENCLOSURE MUST BE CONNECTED TO A GOOD EARTH GROUND.

L1 L2 3 5 6 7 D1 D2
 Ⓞ Ⓞ Ⓞ Ⓞ Ⓞ Ⓞ Ⓞ Ⓞ

SCHEMATIC, TYPE DHC, 1 PHASE

INCOMING SERVICE

200, 230 OR 460 VAC
3 PH
60 HZ

MOTOR DATA


200 VAC , M-25 HTR
1 HP AT 4.1 F.R.A.
230 VAC , M-24 HTR
1 HP AT 3.6 F.R.A.
460 VAC , M-17 HTR
1 HP AT 1.8 F.R.A.

NOTE

MOTOR BRANCH CIRCUIT
PROTECTION MUST BE
PROVIDED BEFORE THIS
CONTROL PANEL.

TRANSFORMER CONNECTION

- 200 V
- 230 V
- 460 V




NOTE 
ENCLOSURE MUST BE
CONNECTED TO A GOOD
EARTH GROUND.

- L1
- L2
- L3
- 3
- 5
- 6
- 7
- DI
- D2

SCHEMATIC, TYPE DHC, 3 PHASE

Figure 5



TROUBLE SHOOTING

Basically, there are only three adjustments that can be made to any hydraulic power unit that DLM, Inc. installs on its hydraulic powered dock levelers. To help simplify the adjustment of these power units, the three main adjustment valves will be labeled A, B, C. These same three valves will also be color coded in the event one or more of the tag labels is removed. Tag "A" will be color coded in red. Tag "B" will be color coded in white, and tag "C" will be color coded in blue. The following is a list of possible problems and the correct adjustments for solving these problems. Valve C should not be adjusted before first contacting the customer service department at DLM, Inc.

WARNING

Before making any adjustments to hydraulic powered dock levelers, first, raise the leveler to the upright position and install the maintenance strut.

PROBLEM: Unit raises but the lip plate will not retract.

SOLUTION: Turn valve "A" (Red) clockwise approximately 1/2 turn and retest unit. If the lip plate still will not retract, repeat the above adjustment until unit operates properly. Unit raises but the lip plate will not extend.

PROBLEM: The unit raises slowly, the motor is extremely noisy, and the hydraulic hoses are vibrating.

SOLUTION: Check the fluid level in power unit reservoir, if low, add fluid and operate leveler several times to remove any air from the system.

PROBLEM: Lip Plate will not stay extended.

SOLUTION: Turn valve "B" (White) clockwise in 1/2 turn increments until lip plate remains extended, but is still yieldable to approximately thirty pounds of downward force.

PROBLEM: The lip plate extends before the unit reaches full dock height.

SOLUTION: Turn valve "A" (Red) clockwise in 1/2 turn increments until lip plate operates properly.

PROBLEM: The motor runs but the unit will not raise.

SOLUTION: Check the motor for reverse polarity wiring. Consult the wiring diagram located on the motor and reverse polarity according to the diagram.

TROUBLE SHOOTING (continued)

PROBLEM: Unit raises very slow.

SOLUTION: Check for voltage drop due to wrong size wiring. Check fluid level.

PROBLEM: Unit raises but control box shuts off during operating cycle.

SOLUTION: Check the overload relay located in the control box and adjust if necessary.

PROBLEM: Unit has no yieldable lip. Lip will not yield to hand force.

SOLUTION: Turn valve "B" (White) counter-clockwise in 1/2 turn increments until lip plate will remain extended but still yield to approximately thirty pounds of downward force.

PROBLEM: Unit will not raise to full dock height.

SOLUTION: Check fluid level in reservoir. Fluid level should be three inches below the top of the reservoir with all cylinders fully extended.

WARNING

Always be sure to use the maintenance strut and close the flow control on the main cylinder before you get under any hydraulic leveler.

MAINTENANCE

Dirt is the single greatest threat to hydraulic system reliability. Each dirt particle generates additional particles due to abrasive action. Care should then be taken to prevent dirt from entering the system. Failure to follow standard hydraulic service procedures may allow foreign particles to be introduced into the system causing accelerated wear, sticking of parts, loss of efficiency, and premature failure of components.

CAUTION: Wipe all foreign material from around fill port prior to removing fill port cap.

For proper operation, cleaning and lubrication should be performed every 90 days or sooner, depending on usage.

Grease all fittings on piano hinges and oil cylinder pivots every 90 days. At this time inspect all hoses and fittings, replace any worn parts. Check fluid level using dipstick. Oil level should be within 3 inches of top of reservoir with cylinders fully extended.

CAUTION: Do not attempt to cycle or operate leveler while personnel are in the vicinity of the lip or ramp plate of the leveler. This may result in personal injury and/or property damage.

DLM, Inc. prides itself in offering a truly superior dock leveler at an affordable price. Our dedication to quality is represented in carefully engineered and efficient designs, superior welding and attention to details that ensure years of rugged service. For continued reliability use only genuine DLM replacement parts, this will insure the structural and operational integrity of the leveler. Please lubricate your DLM dock levelers, exercise common sense in the use and operation of the levelers and observe safe work habits.

DLM, Inc. warrants that its products will be free from defects in design, materials and workmanship for a period of one year from date of shipment. All claims for breach of this warranty must be made within thirty days after the defect is or can, with reasonable care, be detected, and in no event more than 395 days after shipment. To be entitled to the benefits of this warranty, the product must have been properly installed, maintained, operated within its rated capacity and not otherwise abused. This warranty is DLM, Inc's exclusive express warranty.

In the event of any defects covered by this warranty, DLM, Inc. will remedy such defects by repairing or replacing any parts found to be defective. This warranty is limited to parts only and does not include labor to remove, replace, install or adjust the product. This shall be the exclusive remedy for all claims whether based on contract, negligence, or strict liability. DLM, Inc. shall not in any event be liable for any loss of the use of any equipment or incidental or consequential damages of any kind.

DLM, Inc. expressly disclaims all implied warranties including the implied warranties of merchantability and fitness.

